



**DESCRIPTION: 2100 DELTA FORCE™ FAST GRAB PREMIUM CARPET ADHESIVE**

Taylor 2100 is a fast tacking, solvent free, premium adhesive for the interior installation of both direct glue down and double stick carpet installations. This adhesive has been specially designed to provide quick grab with fast wet suction and holding power for bonding the most difficult to install carpet backings. Do not use outdoors.

**USE TO INSTALL:** Carpet backings: jute, latex unitary (smooth and rough), hot melt, polypropylene (ActionBac®), needle punched, and all backings designed for the installation of direct glue down carpet. Do not use to install vinyl-backed carpets. This non-staining formula can also be used on felt back resilient flooring.

**USE OVER:** Concrete: above, on or below grade in the absence of excessive moisture and alkali; APA registered plywood underlayment; association grade particleboard. *Not recommended over existing vinyl flooring.* The pH level of concrete must be between 5 and 9 (do not install if over 9) and moisture level of concrete must be below 5 lbs./1000 sq. ft./24 hours using an anhydrous calcium chloride test kit according to ASTM F-1869 test method. Relative Humidity readings according to ASTM F-2170 should not exceed (RH) 90%. If both tests are performed, the RH test is the qualifying standard.

**FLOOR PREPARATION:** Floor must be clean, level and dry. Remove all foreign substances such as wax, grease, dirt and any substance or chemical that would interfere with a good bond. Fill all holes and cracks with a latex fortified Portland cement based patching compound. Sand high spots, install association grade plywood or particleboard underlayment over tongue and groove flooring to eliminate the possibility of telegraphing. For best results, the room, floor covering and adhesive should be 65° F (18° C) or above for 24 hours before, during and after the installation.

**TROWEL RECOMMENDATIONS:**

Flooring Product	Trowel Size* and Notch	Coverage
Smooth Backed Carpet:	3/32" x 3/32" x 3/32" V-Notch 2.4mm x 2.4 mm x 2.4mm	Up to 160 sq. ft./gal Up to 3.9 sq. meters/liter
Most Backed Carpet	1/8" x 1/8" x 1/16" V-Notch 3.2 mm x 3.2 mm x 1.6 mm	Up to 110 sq. ft./gal Up to 2.7 sq. meters/liter
Rough Back Carpet and Double Stick to Cushion	1/8" x 1/8" x 1/16" U-Notch 3.2 mm x 3.2 mm x 1.6 mm	Up to 72 sq. ft./gal Up to 1.8 sq. meters/liter
Felt Backed Resilient	1/16" x 1/16" x 1/16" square notch 1.6mm x 1.6 mm x 1.6mm	Up to 250 sq. ft./gal Up to 6.1 sq. meters/liter

\*Trowel dimensions are width x depth x spacing

**INSTRUCTIONS**

1. Apply adhesive to substrate with the recommended notch trowel (trowel size will depend on the type of backing and smoothness of the substrate). Minimum trowel size for most carpets 3/32" x 3/32" x 3/32" (2.4mm x 2.4mm x 2.4mm) V-notch. Lay most floor coverings into wet adhesive. Open time will vary from 15 minutes to one hour, depending on the dryness of the floor, thickness of adhesive application, temperature and humidity. When installing on a non-porous surface, allow adhesive to get slightly "tacky" before laying in carpet.
2. Lay in flooring, lifting occasionally to be sure of making 100% adhesive contact with carpet/sheet vinyl backing.
3. Roll carpet immediately after installation with a 30-50 lb. (13.6-22.7 kg) roller. Work from the center towards the edges to expel trapped air. Use a carpet tube for double-stick installation. Roll sheet goods with a linoleum roller. Work from the center towards the edges to expel trapped air.
4. Seal all seams according to the flooring manufacturer's recommendations. For carpet, use Taylor 2075/775 Carpet Seam Adhesive.
5. Clean up: Use soap and water if adhesive is still wet. If dried, use Taylor Touchdown #9 Adhesive Remover/Stripper.

**PHYSICAL PROPERTIES**

Base: Synthetic rubber, resin blend  
 Appearance: Off-white, smooth, easy to spread mastic  
 Working time: 15-60 minutes under normal conditions  
 Shelf life: One year in unopened container at 70° F (21° C).  
 Other features: Solvent-free, non-flammable, freeze/thaw stable to 10° F (-12° C). Made with anti-microbial agents that will provide its dry film with protection from fungal growth. This protection is determined using the ASTM G21 test method.

**CAUTION:** DO NOT take internally. If swallowed, DO NOT induce vomiting. Call a physician immediately. KEEP OUT OF REACH OF CHILDREN.

**WARRANTY INFORMATION:** This product is manufactured according to exacting quality control standards and is warranted to be free from manufacturing defects. Defective material called to our attention within one year of manufacture will be replaced. No guarantee, expressed or implied, is made regarding the performance of this product since the manner and conditions of application are beyond our control. For complete warranty information, call Technical Services at 800-868-4583; visit us on the web at [www.wftaylor.com](http://www.wftaylor.com); or e-mail us at [info@wftaylor.com](mailto:info@wftaylor.com).